

Cabinetware Cutlist Setup Instruction

1. To access the Cabinetware INI file, click the HELP button,
2. Chose the "About Cabinetware" option.
3. A popup opens up.
4. Click the Cabinetware icon on the popup and the INI file will open up.
5. Find the CUTLIST heading in the INI file
6. Look in the lines immediately following for a line that says "LCD=".
7. Change that line to "LCD=B".
8. The INI file must be manually saved and
9. Restart Cabinetware to engage the changes.
10. Now whenever you create a cut list, the .b file will be created in addition to the file you need for your CNC.

With Cabinetware you only have to pay if you want the .rzg file output and for that you need NC center (I've also heard it called Screen to Machine).

This is \$10K if you don't already have it. Folks who are downloading to a CNC router have it. The advantage to going through NC Center is that all the export files are created simultaneously.

With a .cut file (Cabinet Vision with conversion utility \$500 last I heard) it requires another set of mouse clicks. According to my sources as reflected in the .b instructions, in CabinetWare using .b files are created simultaneously as well.