

Technical Services, Inc. - Razor Optimal MD (1.31) - [OPERATION]

PARTS LIST

LABELS

DIAGNOSTICS

VIEW CUT PARTS

MORE

Purge Printer

EXIT

OPEN PARTS FILE 1

CURRENT STOCK TYPE

#	12 OF 12
PANEL NO	
MATERIAL	3/4 Hickory
WIDTH	2
TOTAL	786.5
SHORT	10
LONG	40.25

MOVE TO SCAN START

SCAN & GO

SCAN & WAIT

CANCEL SCAN

GO

PAUSE RUN

QUEUED BOARD

SAW STOP

LIST TYPES 3

POSITION	98.2783
MOVE	
ACTION	

PARTS CUT	2333
OPERATOR	JIM
SUPPLIER	MIGHTY OAK

1 Press **Open Parts File**

2 Select the cutlist you want to open. When the cutlist opens, it will be sorted by material type. Types are determined by the species, thickness, and width of the wood.

3 Choose a type you wish to run. Use the navigation keys to change type. Use the **List Types** button to see all remaining types.

4 Place a piece of stock matching the material type you are running on the table.