

Location of Serial Number on RazorGage AT and ST

The easiest place to find the serial number on a RazorGage is in the RazorGage software. After you have started up the software and homed the machine, the RazorGage serial number and software version is displayed HERE:



On MOST versions of the RazorGage AT the Serial Number is stamped HERE.



On EARLY versions of the RazorGage AT the Serial Number is stamped HERE.


THE SERIAL NUMBER CAN ALSO BE FOUND ON THE JUMP DRIVE TAG. THIS JUMP DRIVE CAN BE FOUND HANGING INSIDE THE ELECTRICAL ENCLOSURE ON THE DINSIDE OF THE DOOR.



Location of Serial Number on RazorGage ST

SERIAL NUMBER MAY BE STAMPED HERE

SERIAL NUMBER MAY BE STAMPED ON THE BACK NEXT TO THE MOTOR HERE



THE SERIAL NUMBER CAN ALSO BE FOUND ON THE JUMP DRIVE TAG. THIS JUMP DRIVE CAN BE FOUND HANGING INSIDE THE ELECTRICAL ENCLOSURE ON THE DINSIDE OF THE DOOR.

